



BACKSET FROM CENTER OF DOOR EDGE

MIN. CLEARANCE FOR 7500 LOCK. 4 13/16 MIN. CLEARANCE FOR SS7500 LOCK.

LHR SHOWN  
RHR OPPOSITE

WIRING FOR E7500 & SS7500 LOCKS: GO THRU DOOR AND NOT DEVICE. MINIMUM RACEWAY CLEARANCE IS 1/4" Ø.

NOTE: MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR. FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED, SEE ADDITIONAL TRIM TEMPLATE.

### 5575 & 5575-F Mortise Lock Device (Wood Door)

# VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W10068\_a

DATE: 05-29-13