



NOTES:

1. FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED, SEE TRIM TEMPLATE
2. MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR,
3. SEE TEMPLATE #30038 IN HOLLOW METAL TEMPLATE BOOK FOR 338 STRIKE.
4. DOOR EDGING SHOULD BE INSTALLED AFTER DEVICE INSTALLATION.

(11)

LHR APPLICATION SHOWN,
RHR APPLICATION OPPOSITE

**5547WDC & 5547WDC-F Series
Vertical Rod Devices (Wood Door)**

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE
NUMBER:

W10080_a

DATE:
05-29-13