


# Architectural Door Accessories

## McKinney “PoE” (Power over Ethernet) Concealed Circuit Hinge

The global leader in door opening solutions



### Connector Color Codes

Connector Positions for wires									
6 CKT						4 CKT			
Pin # 1	Pin # 2	Pin # 3	Pin # 4	Pin # 5	Pin # 6	Pin # 1	Pin # 2	Pin # 3	Pin # 4
White/Blue	Blue	White/Brown	Brown		Green/Yellow	White/Orange	Orange	White/Green	Green

The MCKINNEY “PoE” Concealed Circuit Hinge is an intermediate connector which allows for the passage of a constant flow of current between the source of power and the actuated devices in the door, i.e. PoE devices, etc. regardless of the door position.

**NOTE: Door and frame should be prepared per the proper Hinge Template before beginning to assemble the “PoE” Hinge to them. Templates can be downloaded, if desired, from our website at [www.mckinneyhinge.com](http://www.mckinneyhinge.com).**

#### WIRE SPECIFICATIONS:

- 2 twisted pairs (26 AWG)
- 4 straight conductor (28 AWG)
- 1 straight conductor (24 AWG)

#### ELECTRICAL RATING:

361 mA continuous @ 57 volts DC

#### LOCATION:

The “PoE” Hinge should be located in the second from the bottom hinge preparation on the door and frame.

#### INSTALLATION:

**NOTE: Do not try to disassemble the hinge. Serious damage will occur and void any warranty. Wire access holes must be burr free to avoid**

**damaging wires. Before attaching any wires make sure that the hinge will fit properly in the mortise without any binding or pinching of wires.**

Connect the **Harness Assembly(ies)** to the door frame side and door side in the second from the bottom hinge position on the frame.

Slide the **Male Connect(s)** on the **Harness Assembly(ies)** on to the Female Connection(s) on the hinge. Being careful not to damage any wires, push any excess wire and the connection(s) through the access hole(s) in the hinge reinforcing on the jamb into the mortar guard, which is attached to the frame. Attach the hinge leaf to the jamb using the screws provided.

Slide the **Female Connection(s)** into the **Male Connect(s)** located in the second from the bottom hinge preparation on the door. Being careful not to damage any wires, push any excess wire and the connection(s) through the access hole(s) in the hinge reinforcing on metal doors or into the pocket on wood doors or doors with cores. Attach the hinge leaf to the door using the screws provided.